

4064 Peavey Rd. Chaska, MN 55318 Toll Free: 866-933-2935 www.safetypg.com

LADDER GUARD ON **FLAT IRON LADDER**

Paul Boyum P/N: 100389 30 November 2016


REVISION:

C

Page 1 of 6

RECOMMENDED TOOLS FOR ASSEMBLY:

Two people are recommended for installation Drill with 3/8" Drill Bit Socket Set Sharpie Marker or Equivalent



LADDER GUARD ON ANGLE IRON LADDER

- 1. Align the handle onto the holes in the ladder guard.
- Insert the hex bolts through the handle and door holes.




4064 Peavey Rd. Chaska, MN 55318 Toll Free: 866-933-2935 www.safetypg.com Paul Boyum P/N: 100389 DATE: 30 November 2016

Page **2** of **6**


REVISION:

C

3. Fasten the nylock nuts onto the bolts, securing the handle to the door.



- 4. Align the hinges on the door with the ladder.
 - a. The recommended height to the bottom of the ladder from the ground is 24 inches.



- b. The hinges should be parallel with the ladder rail.
- c. The center of the hinge holes should be ¾" from the outside edge of the ladder rail.



4064 Peavey Rd. Chaska, MN 55318 Toll Free: 866-933-2935 www.safetypg.com

P/N: 100389


Paul Boyum

DATE: 30 November 2016


REVISION:

Page 3 of 6

5. Mark the hinge holes to be drilled into the ladder rail.



- 6. Drill the hinge holes into the ladder rail.
 - a. The appropriate drill size is 3/8".
- 7. Realign the ladder hinges with the drilled holes on the ladder rail.
- 8. Insert the carriage bolts through the door hinges.
- 9. Place the hinge spacers onto the bolts and against the door hinges.
- 10. Place the ladder guard against the ladder, ensuring that the carriage bolts pass through the drilled holes in the ladder rail.
- 11. Place the washers onto the carriage bolts.
- 12. Thread the nylock nuts onto the carriage bolts and secure the ladder guard to the ladder.



- 13. Close the ladder guard onto the ladder and check the closed alignment.
 - a. The closed edge of the ladder guard should be parallel with the ladder rail.



4064 Peavey Rd. Chaska, MN 55318 Toll Free: 866-933-2935

www.safetypg.com

Paul Boyum DATE: 30 November 2016


P/N: 100389

Page 4 of 6


REVISION:

C

- i. Make any necessary adjustments before continuing.
- 14. There are two variations for securing the ladder guard to the ladder with a padlock.
 - a. Proceed to step 15 for angle iron ladders.
 - b. Proceed to step 16 for flat iron ladders.
- 15. For angle iron ladders:
 - a. With the ladder guard closed, mark the hole to be drilled for the padlock.



- b. Open the ladder guard and drill the padlock hole.
- 16. For flat iron ladders:
 - a. Close the ladder guard.
 - b. Place the padlock bracket into the gap between the ladder guard and ladder rail.
 - i. If there is a large space between the ladder and the Ladderguard proceed to step 17.
 - c. Align the padlock bracket slot with the hole in the ladder guard furthest away from the ladder
 - d. Hold the padlock bracket in place and open the ladder guard and mark drill holes.





4064 Peavey Rd. Chaska, MN 55318 Toll Free: 866-933-2935 www.safetypg.com

P/N: 100389


Paul Boyum

30 November 2016

REVISION:

Page 5 of 6

- Remove the padlock bracket and drill the padlock bracket holes.
- Place the hex bolts through the padlock bracket and into the ladder rail.
- Place the washers onto the bolts.
- Thread the nylock nuts onto the hex bolts and secure the padlock bracket onto the ladder rail.



- Close the ladder guard and check closed alignment.
 - i. Make adjustments if necessary to ensure the padlock will smoothly pass through the ladder guard and padlock bracket.
- 17. For ladders with a large space between the ladder and the Ladderguard:
 - a. Align the padlock bracket slot with the hole in the ladder guard furthest away from the ladder
 - b. Hold the padlock bracket in place and open the ladder guard and mark the drill holes.
 - c. Remove the padlock bracket and drill the padlock bracket holes.
 - d. Place the hex bolts through the padlock bracket and bracket spacer into the ladder rail.
 - e. Place the washers onto the bolts.
 - Thread the nylock nuts onto the hex bolts and secure the padlock bracket onto the ladder rail.



4064 Peavey Rd. Chaska, MN 55318 Toll Free: 866-933-2935 www.safetypg.com

P/N: 100389


Paul Boyum

DATE: 30 November 2016

REVISION:

Page 6 of 6

С



- g. Close the ladder guard and check closed alignment.
 - i. Make adjustments if necessary to ensure the padlock will smoothly pass through the ladder guard and padlock bracket.

ANNUAL INSPECTION PROCEDURE

- CHECK FOR ANY LOOSE OR MISSING FASTENERS. TIGHTEN OR REPLACE AS NECESSARY.
 - IF DOOR GUARD IS BENT OR DAMAGED, REPLACE.